

Rear Exhaust Pipe Removal/ Installation

Remove the seat.

Remove the engine mounting bolt and the collar.

Remove the exhaust muffler.

Remove the rear exhaust pipe joint nut, then disconnect the exhaust pipe by pulling up.

Installation is in the reverse order of removal.

At installation: Replace the gasket with the new one.

