

NOTE

- Replace the pivot bearing and outer race as a set.

Requisite Service

- Place the motorcycle on its center stand.

13-3
• Rear wheel removal (page 12-9)

Procedure		Q'ty	Remarks
Removal Order			
(1)	Chain cover/bolt	1/2	
(2)	Brake hose clamp bolt	2	
(3)	Rear brake caliper	1	Remove it from the rear fork.
(4)	Cushion arm bolt/nut (swingarm side)	1/1	
(5)	Shock absorber lower mounting bolt/nut	1/1	
(6)	Swingarm pivot nut	1	
(7)	Swingarm pivot lock nut	1	
(8)	Swingarm pivot bolt	1	
(9)	Swingarm pivot adjusting bolt	1	
(10)	Swingarm	1	
(11)	Left swingarm side collar	1	
(12)	Right swingarm side collar	1	

Swingarm Installation

Screw in the swing arm pivot adjust bolt until it touches the right swingarm side collar.

Install the swingarm. Install the pivot bolt through the adjust bolt engage properly.
Tighten the adjust bolt to the specified torque by turning the pivot bolt.

Torque: 15N·m (1.5kg-m, 11ft-lb)

