

Requisite Service

- Engine oil draining (page ³⁻⁷~~3-11~~)

Procedure		Q'ty	Remarks
(1)	Removal Order		Installation is in the reverse order of removal.
(2)	Clutch cable lock nut	1	Loosen it.
(3)	Clutch cable stay bolt	2	
(4)	Clutch cable stay	1	
(5)	Clutch cable	1	Disconnect from the clutch lifter arm.
(6)	Right crankcase cover bolt	10	
(7)	Clutch cable clamp	1	
(8)	Right crankcase cover	1	
(9)	Gasket	1	
(10)	Dowel pin	2	
(11)	Lifter rod	1	
(12)	Snap ring	1	
(13)	Spring	1	
(14)	Lifter rod	1	
(15)	Dust seal	1	
(16)	Needle bearing	2	