

Fuel Tank Removal/Installation

WARNING

- Gasoline is extremely flammable and is explosive under certain conditions. Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.
- Wipe up the spilled gasoline immediately.

Turn the fuel valve OFF.

Remove the fuel tank mounting bolt.

Slide the tank rearward while pushing down the tank on the front.

CAUTION:

- Make sure that the tank stay is released from the frame plate.

Disconnect the fuel tube and vacuum tube from the fuel tank.

Remove the fuel tank.

Installation is in the reverse order of removal.

CAUTION:

- Before tightening the fuel tank mounting bolt, make sure that the fuel tank stay and the frame plate are engaged securely.
- Do not remove the seal rubber in the front of the fuel tank, or there may be engine trouble in rain/ after washing.

After installation, turn the fuel valve ON and check for the gasoline leaks.

