

Troubleshooting

⚠ WARNING

- If the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area.

Battery Undercharging

NOTE

- In order to obtain accurate test readings when charging system, the battery must be fully charged and in good condition. See Common Service Manual section 22 for check the battery condition.

