

(Cont'd)

Description	Tool Number	Applicability	Refer Section (s)
Steering stem socket Ball race remover set(①-⑥) ① Driver shaft assembly (Includes nuts A and B) ② Assembly base ③ Driver attachment A ④ Driver attachment B ⑤ Bearing remover A ⑥ Bearing remover B Steering stem driver Fork seal driver body Fork seal driver attachment	07916-3710100 07946-KM90001 07946-KM90300 07946-KM90600 07946-KM90100 07946-KM90200 07946-KM90401 07946-KM90500 07946-MB00000 07747-0010100 07747-0010600	Top thread removal/installation Steering head outer race removal/ installation Steering lower bearing inner race installation Fork oil seal installation	11
Shock absorber compressor Shock absorber compressor screw Shock absorber compressor attachment Needle bearing remover Driver handle A Outer driver 24×26mm Pilot 17mm Driver shaft Needle bearing remover Outer driver 32×35mm Pilot 15mm Outer driver 28×30mm Pilot 22mm Lock nut wrench	07G1E-0010000 07G1E-0010100 07959-MB10000 07G1D-KT80100 07749-0010000 07746-0010700 07746-0040400 07946-MJ00100 07G1D-KT70200 07746-0010100 07746-0040300 07946-1870100 07746-0041000 07G1A-KT70200	Shock absorber disassembly/ assembly Cushion connecting rod bearing removal Shock absorber lower bearing removal Cushion arm(swingarm:cushion arm side) bearing installation Cushion connecting rod bearing installation Shock absorber lower bearing installa- tion Cushion connecting rod bearing installation Right swingarm bearing removal Left swingarm bearing removal Left swingarm bearing removal Right swingarm bearing installa- tion Left swingarm bearing installation Cushion arm (swingarm:cushion arm side) bearing installation Swingarm lock nut removal/installation	12