

WARNING

- Do not get grease on the brake disc or stopping power will be reduced.
- Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.
- Check the brake system with applied the brake after the air bleeding.

CAUTION:

- Spilled brake fluid will damage painted, plastic, or rubber parts.

Requisite Service

- Brake fluid draining/air bleeding

Procedure		Q'ty	Remarks
(1)	Disassembly Order		Assembly is in the reverse order of removal.
(2)	Pad pin plug	1	
(3)	Pad pin	1	At installation: Apply a thin coat silicone grease.
(4)	Front brake pad	2	Replacement (page 13-2) 14-2
(5)	Bracket	1	Remove from the caliper body.
(6)	Pad spring	1	
(7)	Retainer	1	
(8)	Boot	1	Replace a damaged boot with a new one.
(9)	Bushing	1	Replace a damaged bushing with a new one.
(10)	Bleeder/cap	1/1	
(11)	Caliper piston	2	
(12)	Dust seal	2	CAUTION: • Be careful not to damage the piston sliding surface.
(13)	Piston seal	2	
	Caliper body	1	